

How to Install your Gray Water Bucket

Step 1:



*Dig a Hole 18" deep and 18" wide.

*Add 5" to 6" deep of river rock Approximately the size of a baseball.

Step 2:



*Place Bucket upside down.

(The inverted bucket has a hole for adding your gray water. It helps to hold bucket down by adding some rock around the outside of the bucket)

Step 3:



*Fill bucket with river rock through the hole in the top of the bucket. (Leaving some room at the top will help it from overflowing when gray water is dumped.)

Step 4:



*Rake dirt and rock around bucket and the goal is to have 1" to 2" of the bucket visible.

Step 5:



*Your finished product!

HELPFUL TIPS

- Put this near the dump port of your trailer.
- Or put it close to your camp kitchen.
- Should be in a low traffic area.